

## **LINE SET LENGTH ADJUSTMENT:**

1. STAKE DOWN ENDS OF ALL LINES AND UNWIND FROM WINDER, LAYING OUT ON THE GROUND.
2. SEPARATE ALL LINES STARTING AT STAKED END, MAKING SURE THERE ARE NO TWISTS OR TANGLES.
3. UNDO THE KNOTS ON THE FREE ENDS AND SLIDE SLEEVING APPROX. 2 FEET TOWARDS THE STAKED END.
4. PICK THE SHORTEST LINE AND TIE A SMALL LOOP AT ITS END – STAKE DOWN THIS LINE WHILE UNDER TENSION.
5. MARK A SET POINT WITH BLACK MARKER (APPROX 2” FROM THE LOOP).
6. TAKE OTHER LINES (ONE AT A TIME), APPLY SLIGHT TENSION AND MARK THEM AT THE SAME SPOT AS ABOVE.
7. SLIDE THE END OF THE SLEEVING TO THIS MARK.
8. PINCH THE END OF THE SLEEVING AT THE MARK, USE THE OTHER HAND TO TEASE THE SLEEVING AWAY FROM THE MARK SEVERAL TIMES (STRETCHING/STIFFENING SLEEVING)
9. FOLD THE SLEEVING END TO END, THEN TIE AND OVERHAND KNOT NEAR THE END OF THE SLEEVING.
10. WHEN YOU FINISH ALL FOUR LINE ENDS, CHECK FOR PROPER LENGTH & ADJUST IF NEEDED.
11. TIE A SECOND OVERHAND KNOT APPROX ½” ABOVE FIRST KNOT.
12. CUT OFF EXCESS LINES AND GO KITING!!!